



### Printing

- Design or select your image on the computer.
- Do **NOT** set your printer to mirror the image. Use the standard printing orientation.
- Print your image on the coated side of the transfer paper (The duller, rougher white side is the coated side) (Do **NOT** print on the shiny white side. That is the backing/support paper)
- Allow the printed image to dry before transferring. Depending upon your printer settings, the transfer will typically be ready for application immediately.

**DO NOT OVERSATURATE COLORS. IT WILL NOT ENHANCE TRANSFER QUALITY. A LITTLE COLOR WILL GO A LONG WAY.**  
Suggested Printer setting

Printer	Paper Setting	Image Quality Setting
Lexmark	T-shirt Transfer	Best
HP DeskJet	T-shirt Transfer	Best
Canon	T-shirt Transfer	Default
Epson C86/C88	Plain Paper	Photo / Best Photo
Epson 1280	360 DPI	Photo / Best Photo
Epson R200	Photo-Quality inkjet	Photo / Best Photo
Epson 4000	Photo-Quality inkjet	Automatic



### Commercial Heat Press Application

- Set heat press at 375 degrees Fahrenheit and allow to come to set point
- Set press for medium pressure
- Pre-heat garment for a few seconds to remove moisture or wrinkles
- Starting from the edge or corner, gently peel the printed transfer sheet from the support/backing paper. You can discard the support/backing paper.
- Place transfer on the fabric or garment with the **image facing UP**
- Cover the entire image area with the enclosed parchment paper and press for 10 seconds
- Parchment paper can be removed hot or cold



### Home Iron Application

- It is best to use a smooth, hard, non-porous surface
- Preheat the iron on the highest setting (**Cotton/Linen**). Do not add water to the iron
- Allow the iron to pre-heat for 5 minutes
- Place a pillowcase on the ironing surface. Iron to remove wrinkles.
- Pre-iron the fabric to remove any moisture and wrinkles
- Starting from the edge or corner, gently peel the printed transfer sheet from the support/backing paper. You can discard the support/backing paper.
- Place transfer on the fabric or garment with the **image facing UP**
- Cover the entire image area with the enclosed parchment paper
- **Using firm pressure, slowly iron over the entire surface with sufficient overlapping (1) side to side (2) bottom to top and (3) along the edge, moving continuously for 2-3 minutes.**
- Parchment paper can be removed hot or cold



### Washing and Drying

- Wash and dry your transfer according to your fabric's normal wash instructions



### Storage

Always store unused paper in a cool and dry area sealed in a plastic bag so paper is not exposed to any excess moisture.

**NOTE:** Testing procedures to simulate real- world use have been established and applied to our paper products in our technical and research department. We have tested our products on a multitude of substrates, using different printers, transfer equipment, detergents, and washing processes, etc. We still recommend that you test the paper on your chosen printer and material as it is impossible to duplicate every printing or transfer application. **PATENT PENDING**